

TECHNICAL CHART 83

GLITTER

Description of product

An additive in powder form, based on lamellar glitter of regular shape, to be used in combination with the Luxury&LIME decorative finishes to obtain a sparkling appearance.

Application field

Metallescent products such as "Crystal Moon", "Metal Paint", and many others.

Product characteristics

GLITTER must be added in the measure of one pack for each liter of chosen product.

Before using GLITTER, manually homogenise the product. Add the content to the desired decorative product and mix thoroughly.

To obtain the best aesthetic result, apply the decorative product obtained by brush.

| Technical data | |
|-----------------|--|
| Name | Glitter |
| Composition | Lamellar glitters |
| Aspect | Powder |
| Color | Silver, Gold |
| Dilution | Ready to use |
| PH | 6 - 8 |
| VOC class | VOC 0 g/l, wall paint and subcategory "L" max.value UE2010 30g/l |
| Specific weight | 0,95 g/cm ³ |
| Packaging | 80 grams packages |
| Storage | The product remains unchanged for at least one year if kept in a closed and sheltered environment at a temperature between 5 - 35 °C. Protect from frost! |
| Notice | <ul style="list-style-type: none"> • Mix the product thoroughly before laying. • Carry out the addition in the time close to laying the finish. • Use the mixed product within 5-6 days. • Do not dispose of residues in the sewers. • The equipment should be washed immediately after use with water. |

GLITTER

Instructions for use

- GLITTER must be added in the measure of one package for each liter of chosen product.
- Mix the product thoroughly before laying.
- Carry out the addition in the time close to laying the finish.
- To know how to apply the product mixed with GLITTER, refer to the technical data sheet of the chosen product.

Note

The present technical chart has been written by Bericalce's experts and the indicated technical and scientific information have been tested in our own workshop.

Any responsibility regarding the results are due only to the method and conditions used during application of the product.

These indications are a valid support for testing the quality of the product in each specific case.

Date of issue 14.09.2016

Data of update 23.02.2017

BeriCalce ITALIA

Via Odorico da Pordenone, 18

36100 Vicenza - ITALIA

Tel./Fax (+39) 0444 929102

Tel. (+39) 0444 923317

Skype: bericalce

info@bericalce.com

bericalce.com